



**Ditting Maschinen AG**


Länggenstrasse 34 | CH-8184 Bachenbülach, Switzerland  
Tel. +41 44 864 18 00 | Fax +41 44 864 18 01  
info@dittingswiss.ch | www.dittingswiss.ch

**SOFTWARE  
MENU**





### OPERATING PARTS



Display



Single shot button



Double shot button












Start / Stop switch


The software menu is guided through the buttons left and right of the display. The symbol in the bottom corners of the display shows the function of the respective button.

To confirm press the Start / Stop switch.

## ICON EXPLANATION

-  to navigate back in the menu
-  to navigate forward in the menu
-  to exit the submenu
-  to open the submenu/confirm your input
-  to reset/turn off
-  to increase the value
-  to decrease the value
  
-  switch to operating time counter
-  switch to total shot counter


## DISPLAY ICONS



## MAIN MENU

### TO ENTER THE MENU

Press and hold for 3 sec




### TO EXIT THE MENU

Press and hold for 3 sec



## COUNTER SETTINGS




### RESET THE COUNTER

Press and hold for 3 sec




## LIGHT SETTINGS



**ADJUSTABLE COLOR**  
intensity for red, green & blue.




## TEMPERATURE SETTINGS



**SHOWS TEMPERATURE**  
inside the grinder.



## ALARM SETTINGS



THIS FUNCTION WORKS ONLY OUTSIDE THE MENU:

### RESET THE CLEAN COUNTER

Press and hold for 10 sec



### RESET THE DISC COUNTER

Press and hold for 20 sec and enter the pin